

ECE 3434 – Advanced Electronic Circuits

Textbook: Adel S. Sedra and Kenneth C. Smith, Microelectronic Circuits, 5th Edition, Oxford 2004

I. Feedback

- A. The General Feedback Structure
- B. Some Properties of Negative Feedback
 - a. Gain Desensitivity
 - b. Bandwidth Extension
 - c. Noise Reduction
 - d. Reduction in Nonlinear Distortion
- C. The Four Basic Feedback Topologies
 - a. Voltage Amplifiers
 - b. Current Amplifiers
 - c. Transconductance Amplifiers
 - d. Transresistance Amplifiers
- D. The Series-Shunt Feedback Amplifier
 - a. The Ideal Situation
 - b. The Practical Situation
- E. s -Domain Analysis: Poles, Zeros, and Bode Plots
- F. The Stability Problem
 - a. Transfer Function of the Feedback Amplifier
 - b. The Nyquist Plot
- G. Effect of Feedback on the Amplifier Poles
 - a. Stability and Pole Location
 - b. Poles of the Feedback Amplifier
 - c. Amplifier with Single-Pole Response
 - d. Amplifier with Two-Pole Response
 - e. Amplifiers with Three or More Poles
- H. Stability Study Using Bode Plots
 - a. Gain and Phase Margins
 - b. Effect of Phase Margin on Closed-Loop Response
 - c. An Alternative Approach for Investigating Stability
- I. SPICE Simulation Example

II. Operational-Amplifier and Data-Converter Circuits

- A. The Two-Stage CMOS Op Amp
 - a. The Circuit
 - b. Input Common-Mode Range and Output Swing
 - c. Voltage Gain
 - d. Frequency Response
 - e. Slew Rate
- B. The Folded-Cascode CMOS Op Amp
 - a. The Circuit
 - b. Input Common-Mode Range and the Output Voltage Swing
 - c. Voltage Gain
 - d. Frequency Response
 - e. Slew Rate
 - f. Increasing the Input Common-Mode Range: Rail-to-Rail Input Operation
 - g. Increasing the Output Voltage Range: The Wide-Swing Current Mirror
- C. The 741 Op-Amp Circuit
 - a. Bias Circuit

- b. Short-Circuit Protection Circuitry
- c. The Input Stage
- d. The Second Stage
- e. The Output Stage
- f. Device Parameters
- D. Data Converters
 - a. Digital Processing of Signals
 - b. Sampling of Analog Signals
 - c. Signal Quantization
 - d. The A/D and D/A Converters as Functional Blocks
- E. D/A Converter Circuits
 - a. Basic Circuit Using Binary-Weighted Resistors
 - b. R - $2R$ Ladders
 - c. A Practical Circuit Implementation
 - d. Current Switches
- F. A/D Converter Circuits
 - a. The Feedback-Type Converter
 - b. The Dual-Slope A/D Converter
 - c. The Parallel or Flash Converter
 - d. The Charge-Redistribution Converter
 - e. SPICE Simulation Example

III. Digital CMOS Logic Circuits

- A. Digital Circuit Design: An Overview
 - a. Digital IC Technologies and Logic-Circuit Families
 - b. Logic-Circuit Characterization
 - c. Styles for Digital System Design
 - d. Design Abstraction and Computer Aids
- B. Design and Performance Analysis of the CMOS Inverter
 - a. Circuit Structure
 - b. Static Operation
 - c. Dynamic Operation
 - d. Dynamic Power Dissipation
- C. CMOS Logic-Gate Circuits
 - a. Basic Structure
 - b. The Two-Input NOR Gate
 - c. The Two-Input NAND Gate
 - d. A Complex Gate
 - e. Obtaining the PUN from the PDN and Vice Versa
 - f. The Exclusive-OR Function
 - g. Summary of the Synthesis Method
 - h. Transistor Sizing
 - i. Effects of Fan-In and Fan-Out on Propagation Delay
- D. Pass-Transistor Logic Circuits
 - a. Operation with NMOS Transistors as Switches
 - b. The Use of CMOS Transmission Gates as Switches
 - c. Pass-Transistor Logic Circuit Examples
- E. Dynamic Logic Circuits
 - a. Basic Principle
 - b. Nonideal Effects
 - c. Domino CMOS Logic

IV. Filters and Tuned Amplifiers

- A. Filter Transmission, Types, and Specification
 - a. Filter Transmission
 - b. Filter Types
 - c. Filter Specification
- B. The Filter Transfer Function
 - a. Butterworth and Chebyshev Filters
 - b. The Butterworth Filter
 - c. The Chebyshev Filter
- C. First-Order and Second-Order Filter Functions
 - a. First-Order Filters
 - b. Second-Order Filter Functions
- D. The Second-Order LCR Resonator
 - a. The Resonator Natural Modes
 - b. Realization of Transmission Zeros
 - c. Realization of the Low-Pass Function
 - d. Realization of the High-Pass Function
 - e. Realization of the Bandpass Function
 - f. Realization of the Notch Functions
 - g. Realization of the All-Pass Function
- E. Second-Order Active Filters Based on Inductor Replacement
 - a. The Antoniou Inductance-Simulation Circuit
 - b. The Op Amp-RC Resonator
 - c. Realization of the Various Filter Types
 - d. The All-Pass Circuit
- F. Second-Order Active Filters Based on the Two-Integrator-Loop Topology
 - a. Derivation of the Two-Integrator-Loop Biquad
 - b. Circuit Implementation
 - c. An Alternative Two-Integrator-Loop Biquad Circuit
- G. Single-Amplifier Biquadratic Active Filters
 - a. Synthesis of the Feedback Loop
 - b. Injecting the Input Signal
 - c. Generation of Equivalent Feedback Loops
- H. Sensitivity
- I. Switched-Capacitor Filters
- J. Tuned Amplifiers
- K. The Basic Principle
- L. Inductor Losses
- M. Use of Transformers
- N. Amplifiers with Multiple Tuned Circuits
- O. The Cascode and the CC-CB Cascade
- P. Synchronous Tuning
- Q. Stagger-Tuning

V. Signal Generators and Waveform-Shaping Circuits

- A. Basic Principles of Sinusoidal Oscillators
 - a. The Oscillator Feedback Loop
 - b. The Oscillation Criterion
 - c. Nonlinear Amplitude Control
 - d. A Popular Limiter Circuit for Amplitude Control

- B. Op Amp-RC Oscillator Circuits
 - a. The Wien-Bridge Oscillator
 - b. The Phase-Shift Oscillator
 - c. The Quadrature Oscillator
 - d. The Active-Filter-Tuned Oscillator
- C. LC and Crystal Oscillators
 - a. LC-Tuned Oscillators
 - b. Crystal Oscillators
- D. Bistable Multivibrators
 - a. The Feedback Loop
 - b. Transfer Characteristics of the Bistable Circuit
 - c. Triggering the Bistable Circuit
 - d. The Bistable Circuit as a Memory Element
 - e. A Bistable Circuit with Noninverting Transfer Characteristics
 - f. Application of the Bistable Circuit as a Comparator
 - g. Making the Output Levels More Precise
- E. Generation of Square and Triangular Waveforms Using Astable Multivibrators
 - a. Operation of the Astable Multivibrator
 - b. Generation of Triangular Waveforms
- F. Generation of a Standardized Pulse--The Monostable Multivibrator
- G. Integrated-Circuit Timers
 - a. The 555 Circuit
 - b. Implementing a Monostable Multivibrator Using the 555 IC
 - c. An Astable Multivibrator Using the 555 IC
- H. Nonlinear Waveform-Shaping Circuits
 - a. The Breakpoint Method
 - b. The Nonlinear-Amplification Method
- I. Precision Rectifier Circuits
- J. Precision Half-Wave Rectifier?The "Superdiode"
- K. An Alternative Circuit
- L. An Application: Measuring AC Voltages
- M. Precision Full-Wave Rectifier
- N. A Precision Bridge Rectifier for Instrumentation Applications
- O. Precision Peak Rectifiers
- P. A Buffered Precision Peak Detector
- Q. A Precision Clamping Circuit

VI. Output Stages and Power Amplifiers

- A. Classification of Output Stages
- B. Class A Output Stage
 - a. Transfer Characteristic
 - b. Signal Waveforms
 - c. Power Dissipation
 - d. Power-Conversion Efficiency
- C. Class B Output Stage
 - a. Circuit Operation
 - b. Transfer Characteristic
 - c. Power-Conversion Efficiency
 - d. Power Dissipation
 - e. Reducing Crossover Distortion
 - f. Single-Supply Operation

- D. Class AB Output Stage
 - a. Circuit Operation
 - b. Output Resistance
- E. Biasing the Class AB Circuit
 - a. Biasing Using Diodes
 - b. Biasing Using the V_{BE} Multiplier
- F. Power BJTs
 - a. Junction Temperature
 - b. Thermal Resistance
 - c. Power Dissipation Versus Temperature
 - d. Transistor Case and Heat Sink
 - e. The BJT Safe Operating Area
 - f. Parameter Values of Power Transistors
- G. Variations on the Class AB Configuration
 - a. Use of Input Emitter Followers
 - b. Use of Compound Devices
 - c. Short-Circuit Protection
 - d. Thermal Shutdown
- H. IC Power Amplifiers
 - a. A Fixed-Gain IC Power Amplifier
 - b. Power Op Amps
 - c. The Bridge Amplifier
- I. MOS Power Transistors
 - a. Structure of the Power MOSFET
 - b. Characteristics of Power MOSFETs
 - c. Temperature Effects
 - d. Comparison with BJTs
 - e. A Class AB Output Stage Utilizing MOSFETs
 - f. SPICE Simulation Example